

CENTER CONSOLE ASSEMBLY


< ON-VEHICLE REPAIR >

CENTER CONSOLE ASSEMBLY

Exploded View

INFOID:000000001160450

CENTER CONSOLE



- | | | |
|---------------------------------------|--|--|
| 1. Indicator assembly (AT/CVT models) | 2. Console finisher assembly (AT/CVT models) | 3. Console finisher assembly (MT models) |
| 4. Cup holder assembly | 5. Console lid assembly | 6. Console box assembly |
| 7. Rear ventilator grille | 8. Console rear finisher | 9. Rear cup holder assembly |
| 10. Inside key antenna | 11. Console rear bracket | 12. Rear ventilator duct |
| 13. Console sub harness | 14. Console body | 15. Console bracket |
| 16. Instrument lower cover (LH) | 17. Instrument lower cover (RH) | |

○ : Clip

△ : Pawl

□ : Metal clip

Removal and Installation

INFOID:000000001451987

REMOVAL

- Put selector lever in drive position. (AT and CVT Models only)

A
B
C
D
E
F
G
H
I
P
K
L
M
N
O
P